


# Secoroc YSP45 pneumatic rock drill



Ref.	Description	Qty	Prod. No.	Product code
1	Front head	1	96000288	962A-1-3312310293
2	Rotation sleeve	1	96000289	962A-1-3312310294
3	Shank bush	1	96000291	962A-1-3312310296
4	Rotation nut	1	96000290	962A-1-3312310295
5	Silencer	1	96000282	962A-1-3312310287
6	Cylinder	1	96000285	962A-1-3312310290
7	Air cylinder	1	96000287	962A-1-3312310292
8	Valve sleeve	1	96000280	962A-1-3312310285
9	Valve	1	96000279	962A-1-3312310284
10	Ratchet	1	96000277	962A-1-3312310282
11	Small seal	3	96000543	9605-1-3312310726
12	Back head	1	96000292	962A-1-3312310298
13	Air tube	1	96000296	962A-1-3312310302
14	Water tube	1	96000297	962A-1-3312310303
15	O-ring	1	96000485	9605-1-3312310632
16	Yx seal ring	1	96000320	962A-1-3312310329
17	Outer pipe	1	96000314	962A-1-3312310320
18	Lower pipe seat	1	96000315	962A-1-3312310324
19	Guide sleeve	1	96000316	962A-1-3312310325
20	Dust sleeve	1	96000317	962A-1-3312310326
21	Spring pad	1	96000535	9616-1-3312310718
22	Foot	1	96000355	9616-1-3312310385
23	Center	1	96000326	9605-1-3312310337
24	Piston rod	1	96000318	962A-1-3312310327
25	Ring	1	96000319	962A-1-3312310328
26	Elastic ring	1	96000333	9616-1-3312310344
27	Water tube nut	1	96000300	962A-1-3312310306
28	Fixing screw	1	96000525	9605-1-3312310705
29	O-ring	1	96000196	962A-1-3312310191
30	Water tube sleeve	1	96000301	962A-1-3312310307
31	Air tube seat	1	96000302	962A-1-3312310308
32	Air tube pad	1	96000176	9605-1-3312310166
33	Valve chest	1	96000278	962A-1-3312310283
34	Rifle nut	1	96000814	9600-1-3312310009
35	Rifle bar	1	96000283	962A-1-3312310288
36	Piston	1	96000284	962A-1-3312310289
37	Guide sleeve assembly	1	96000286	962A-1-3312310291
38	Large rubber pad	1	96000308	962A-1-3312310314
39	O-ring	1	96000481	9605-1-3312310623
40	Water valve	1	96000309	962A-1-3312310315
41	O-ring	2	96000483	9605-1-3312310628
42	Rubber pad	1	96000310	962A-1-3312310316

Ref.	Description	Qty	Prod. No.	Product code
43	Aluminum plug	1	96000313	962A-1-3312310319
44	Water hose swivel	1	96000311	962A-1-3312310317
45	Nut	1	96000312	962A-1-3312310318
46	Water valve spring	1	96000305	962A-1-3312310311
47	Water valve body	1	96000298	962A-1-3312310304
48	Control valve	1	96000293	962A-1-3312310299
49	Lock ring	1	96000294	962A-1-3312310300
50	Air hose nut	1	96000295	962A-1-3312310301
51	O-ring	1	96000488	9605-1-3312310640
52	O-ring	1	96000487	9605-1-3312310635
53	Spring	1	96000179	9605-1-3312310169
54	Lock pin	1	96000180	9605-1-3312310170
55	Expansion ring	1	96000830	9600-1-3312310027
56	O-ring	1	96000482	9605-1-3312310627
57	Dowel pin	1	96000560	9605-1-3312311043
58	Pressure regulating valve	1	96000306	962A-1-3312310312
59	Fixing pin	1	96000177	9605-1-3312310167
60	Hexagon thin nut	1	96000524	9605-1-3312310704
61	Spring pad	1	96000534	9605-1-3312310716
62	Control handle	1	96000307	962A-1-3312310313
63	Hexagon nut	2	96000517	9605-1-3312310695
64	Side bolt	2	96000299	962A-1-3312310305
65	Hexagon thick nut	4	96000518	9605-1-3312310697
66	Handle	1	96000871	962A-1-3312311027
67	Exhaust valve	1	96000325	9605-1-3312310336
68	O-ring	1	96000484	9605-1-3312310629
69	Exhaust valve spring	1	96000324	9605-1-3312310335
70	Exhaust valve body	1	96000322	9605-1-3312310333
71	Exhaust valve button	1	96000323	9605-1-3312310334
72	Fixing pin	1	96000281	962A-1-3312310286
73	Conical spring	4	96000167	9605-1-3312310156
74	Ratchet pawl	4	96000166	9605-1-3312310155
75	Air hose swivel	1	96000303	962A-1-3312310309
76	Connector nut	3	96000304	962A-1-3312310310
77	Rubber tube connector	3	96000186	9605-1-3312310176
78	Wing nut	3	96000185	9605-1-3312310175
79	Hoop	3	96000540	9605-1-3312310723
80	Bolt	2	96000321	962A-1-3312310331
81	Hexagon nut	2	96000523	962A-1-3312310703
82	Spring pad	2	96000536	962A-1-3312310719
83	Water valve	1	96000555	962A-1-3312311026